HYDAC INTERNATIONAL



Open-Center Sectional Directional Control Valve RS 160-EH

Max. pressure: 250 bar Max. flow rate

60 l/min • Pump port: • Working ports: 60 l/min

Table of contents

Product features	
General information and functional description	2
Overview	2
Technical data	4
Characteristic curves	5
Modular structure	6
Example of block specification and type code	7
Inlet plates	8
Inlet plate P15	8
Inlet plate U15	9
Working sections	10
Section types	10
• Spools	11
Working port valves	13
Operation units	14
End plates	15
Solenoid valves and coils	16
Connection type, fastening and tie rods	17
Installation, usage and maintenance information	17
Interconnection examples	18
Dimensions	19
Type code	22
Ordering examples	25

Product features

- Flow-optimized valve design
- Compact size and low weight
- Several connection options for pump and tank
- Applicable for constant and load-sensing pumps
- Symmetrical sections (Inlet plate can be placed left or right)
- Modular design up to 10 working sections
- Operation type is electrohydraulic proportional (with/without mechanical emergency hand lever)
- Shock / anti-cavitation valves for protection of actuators

- Endplate with port for pilot oil supply (optional internal pilot oil supply)
- Two or more valve blocks can be connected in different arrangements
- Areas of application:
 - Outriggers of mobile - Wheel loader machines - Construction machines
 - Municipal machines - Cranes
 - Truck applications - Stationary applications
 - Agriculture machines

General information and functional description

The RS 160-EH is a proportional control valve according to the open-center principle with electro-hydraulic operation.

The maximum flow rate to the working ports A and B is 60 I/min. The spool 2.1 determines the flow rate and the flow direction.


The pressure control valves 2.3.1 and 2.3.2 are providing shifting pressure to the face sides of the main spool 2.1 .

The level of electric current determines the level of pilot pressure and therefore the position of the spool.

Shock / anti-cavitation valves 2.5.1 and 2.5.2 protect the working ports A and B from pressure peaks and/or cavitation.

The check valve 2.2 in the parallel channel P" prevents the load from descending if the spool is moved and the pump does not provide the system with enough pressure (on A and B side).


Overview




- A, B Working ports
- Tank channel
- P' Center channel
- Parallel channel

2.1	Spool
2.2	Check valve
2.3.1	Pressure control valve A side

2.3.2	Pressure control valve B side
2.5.1	Working port valve port A
2.5.2	Working port valve port B






1.0	Inlet plate		2.4	
1.1	Unloading valve	2	.5.1	
1.2	Main relief valve	2	.5.2	
1.3	Parallel channel connection or separation		3.0	
2.0	Working section		3.1	
2.1	Spool		3.2	
2.2	Check valve		3.3	
2.3.1	Pressure control valve port A		3.4	
2.3.2	Pressure control valve port B			


2.4	Mechanical emergency actuation
2.5.1	Working port valve A side
2.5.2	Working port valve B side
3.0	End plate
3.1	Pressure reducing valve for pilot oil supply
3.2	Center channel precharging valve
3.3	Tank connection or high pressure carry over
3.4	Connection or separation pilot drain to tank


⚠ The technical data were measured at a viscosity of 32 mm²/s.


¹⁾ Mating plug-in connectors are not included


Characteristic curves












- ⚠ The characteristic curves were measured with a 16AA-spool (max. volume flow 60 l/min) at a viscosity of 32 mm²/s.
- ⚠ The pressure drop from P1 to T1 will have an additional $\Delta \text{p-Offset}$ of 8 bar while using the center channel precharging valve

Modular structure

The RS 160-EH can be customized to different applications and machines.

The principle sectional design and modular structure consists of an inlet plate, max. 10 working sections and an end plate. A complete control block is defined by a type code system.




Type code structure			
General	RS 16EH / B0		
		nection type B (BSPF of working sections (P) or S (SAE) 1 0 (0 = 10 working sections))
Inlet plate	U15 / Y1A / 250F	1.0.1	Inlet plate U15 / Y1A / 250F
		1.0.2	Inlet plate P15 / /
Working section	BP4E / 11AZ /	2.0.1	Working section BP4E, SP4E
		2.0.2	Working section BP4E, SP4E
		2.3	Electrohydraulic operation EH01A,
		2.4	Mechanical emergency actuation
End plate	E5E2 /	3.0	End plate E5E2 /

Example of block specification and type code

Example: Control block for hydraulic system with center channel precharging valve


Type code	Control block specification		
Valve type	RS 163-EH	RS 160-EH with 3 working sections	
RS163-EH / B0	В0	Connection type BSPP, valve series 0	
Inlet plate	U15	Inlet plate with unloading valve	
U15 / Y1D / 250F	Y1D	Unloading valve, normally open, with 12 V solenoid and connector type Deutsch DT04-2P	
	250F	Main relief valve fixed setting of 250 bar	
Working section 1	BP4E	Working section w/o shock / anti-cavitation valves – parallel section	
BP4E / 12AA / EHA1D	12AA	3 position spool, double acting, neutral position closed, max. flow 20 l/min	
	EHA1D	Electrohydraulic operation, with hand lever axis, mounted on A side 12 V solenoid and connector type Deutsch DT04-2P	
Working sections 2 and 3	SP4E	Working section with shock / anti-cavitation valves – parallel section	
SP4E / 14AA / 180F - A / EHA1D	14AA	3 position spool, double acting, neutral position closed, max. flow 45 l/min	
	180F – A	Working port valve A side fixed setting of 180 bar, anti-cavitation valve B side	
	EHA1D	Electrohydraulic operation, with hand lever axis, mounted on A side 12 V solenoid and connector type Deutsch DT04-2P	
End plate	E5E2	End plate with internal pilot oil supply	
E5E2 / 0C	0C	Z port, center channel precharging valve, no high pressure carry over	














1	Basic ty	уре	
	P	Inlet plate with P2 port (w/o unloading valve)	
	1	Version	
	5	Port size P1 ¹⁾	
2	Main re	lief valve ²⁾	
	F	Pressure setting in bar, 3-digit, fixed set, max. 250 bar (TBS)	
	Р	Plug screw (P110)	
3	Cavity f	or fitting	
	0	Parallel channel connected to center channel	
	1	Parallel channel disconnected from center channel (K16)	
	L	Throttled connection (Loadsensing pumps) on request (L16)	

¹⁾ see section – Connection type, fastening and tie rods

Fitting in cavity pos. 3:

- Parallel channel connected to center channel w/o fitting (standard)
- Parallel channel disconnected from center channel with fitting K16 "1" (see section – Block connection examples)
- Using a load-sensing pump with fitting L16 "L", use P1 port as load sensing port, pump is connected to P2 port

Example configurations

P15 / 180F / 0

- Inlet plate with P2 port (w/o unloading valve)
- Main relief valve fixed setting of 180 bar
- Parallel channel connected to center channel

P15 / P / 1

- Inlet plate with P2 port (w/o unloading valve)
- No main relief valve
- Parallel channel disconnected from center channel

P15 / 190F / L

- Inlet plate with P2 port (w/o unloading valve)
- Main relief valve fixed setting of 190 bar
- Throttled connection between parallel and center channel for use of load sensing pumps
- The throttle adjustment has to be done individual, on request only

²⁾ see section - Working port valves

Inlet plate U15


Type code


U15 / Y2D / 180F











1 Basic t	уре	
U	Inlet plate with unloading valve, normally open, with manual emergency override	
1	Version	
5	Port size P1 ¹⁾	
2 Solenoi	id (Electrical supply voltage, connector type) ²⁾	
Y	Unloading valve normally open	
1	12 V	
2	24 V	
A	AMP Junior Timer, 2-pin – axial	
D	Deutsch DT04-2P, 2-pin – axial	
Р	Plug screw	
3 Main re	elief valve ³⁾	
F	Pressure setting in bar, 3-digit, fixed set, max. 250 bar (TBS)	
Р	Plug screw (P110)	

¹⁾ see section – Connection type, fastening and tie rods

 \triangle The inlet plate U15 may not be used for load sensing pumps.

Example configurations

U15 / Y2D / 180F

- Inlet plate with unloading valve
- Solenoid 24 V and connector type Deutsch DT04-2P
- Main relief valve fixed setting of 180 bar


U15 / Y1A / P


- Inlet plate with unloading valve
- Solenoid 12 V and connector type AMP Junior Timer
- No main relief valve

²⁾ see section – Solenoid valves and coils

³⁾ see section – Working port valves

■ Working sections BP4E / SP4E





Ports and flange channels

- A, B Working ports
- С Pilot oil
- Ζ Pilot drain
- Т Tank
- Center channel
- Parallel channel

Type code


BP4E / 14AA / ...

SP4E / 12AY / 180F - P / ...









¹⁾ see section - Connection type, fastening and tie rods

Section description

Parallel section

The parallel section is the standard section for RS160-EH valve blocks. The parallel channel is connected continuously with the center channel.

Spools

Type code

SP4E / 12AY / 180F - P / EHB1A-1

Examples

1 2


3

Υ 4 Type

Max. volume flow

Principle

Details



Type 4/3-way (double acting) 3/3-way (single acting) Motor spool

Position definition of the spool

II

I


III

I: Neutral position


II: Volume flow to A

III: Volume flow to B

2 Max. vo	lume flow
_1	10 l/min
_2	20 l/min
_4	45 l/min
_6	60 l/min









4 Release	specification
A	Port A and B closed in neutral position; no further release
Z	Port A and B throttled to tank in neutral position
X	Port A throttled to tank in neutral position
Y	Port B throttled to tank in neutral position
T	Port A and B throttled to tank
U	Port A throttled to tank
W	Port B throttled to tank

 \triangle Other spool types and configurations on request

Characteristic curves for nominal flow rates of spool, without load (measured at 32 mm²/s)




Characteristic curves for nominal flow rates of spool, with 200 bar load (measured at 32 mm²/s)



Working port valves

Type code



Shock / anti-cavitation valves protect the working ports A and B against pressure peaks and cavitation.


 ⚠ Shock / anti-cavitation valves are fixed set ex works. The pressure setting is defined at a flow rate of 10 l/min.


Pressure settings of fixed Shock / anti-cavitation valves


Pressure range: 50 to 250 bar at 10 bar steps


Pressure range	50 – 100	110 – 160	170 – 250
Tolerance in bar	±5	±7	±10

⚠ With pressure settings above 220 bar, the pressure rise at higher flows during the relieving function has to be considered. The max. pressure of 250 bar may not be exceeded. Elevated tank pressure due to high tank return flow must be taken in account as it will raise the valve setting.










Operation units

Type code

SP4E / 12AY / 180F - P / EHB1A-1

EH₀ **1A EHB** 2D Basic type Electrical supply voltage, connector type Mechanical emergency hand lever




Technical data for electrohydraulic pilot valves

Supply voltage	V DC	12	24		
Max. control current	mA	1.500	750		
PWM frequency (recommended) ¹⁾	Hz	100 150			
Coil resistance at 20 °C (± 5 %)	Ω	4,7	20,8		
Duty cycle	%	100			

Connector type and IP protection class (with mating connector mounted and locked)

AMP Junior Timer, 2-pin, axial	up to IP6K6 ²⁾
Deutsch DT04, 2-pin, axial	up to IP6K9K ²⁾
Protective screen µm	125




Basic type Housing with electrohydraulic operation proportional, EH0 w/o emergency hand lever axis Housing with electrohydraulic operation, proportional, **EHA** with emergency hand lever axis on A side Housing with electrohydraulic operation proportional, EHB with emergency hand lever axis on B side

- 1) The PWM frequency is to be optimized depending on the application
- 2) Mating plug-in connectors are not included
- ⚠ Standards ISO 13732-1 and ISO 4413 must be observed in regard to the surface temperatures occurring on the coils.

2 Ele	ctrical supply voltage, connector type
1_	12 V
2_	24 V
_ #	AMP Junior Timer
	Deutsch DT04-2P

Mechanical emergency hand lever Mechanical emergency hand lever Interface of hand lever axis and hand lever: Hexagon 9 mm To reduce the spool hysteresis, the hand lever is not \triangle connected directly to the spool and does not follow the spool movement. Therefore a return stroke (ca. 17°) has to be made until the spool can be moved, using the mechanical emergency hand lever function.

End plates



Type code

The center channel precharging valve 4 (c) provides the center channel with a pressure higher than 8 bar. This ensures that the pilot oil circuit is always supplied sufficiently.

The adapter for the high pressure carry over function (HPCO) 4 (H) is assembled to port T1 of the end plate. Port T1 can no longer be used as a tank port.

Example configurations

E5E2 / ZH

- End plate with internal pilot oil supply
- Pilot drain internally connected to T
- With adapter for high pressure carry over (HPCO)

E5E1 / 0H

- End plate with external pilot oil supply
- External port for pilot drain
- With adapter for high pressure carry over (HPCO)

E5E2 / 0C

- End plate with internal pilot oil supply
- External port for pilot drain
- With center channel precharging valve

1	Basic ty	ре
	E	End plate
	_5	Port size T1 ¹⁾
	E_	electrohydraulic
2	Pilot pre	essure supply
	1	external pilot pressure oil supply
	2	internal pilot pressure oil supply
3	Pilot dra	in
	0_	Pilot drain external
	Z_	Pilot drain internally connected to T
4	Center c	channel precharging valve / HPCO
	_ C	with center channel precharging valve
	_H	with high pressure carry over (S16)
	_ 0	w/o option

¹⁾ see section – Connection type, fastening and tie rods


Solenoid valves and coils

Electrohydraulic pilot valves: see section – Operation units

Unloading valve for inlet plate U15:

On/Off valve:


With manual emergency operation (push-button)



Valve type		Poppe	et valve
Nominal voltage U _N	V DC	12	24
Nominal current I _N	А	1,5	0,8
Min. current I _{min}	А	1,05	0,56
Nominal power P _N	W	18	19
Response time	On: ms	;	35
	Off: ms		50
Max. permitted voltage deviation from U _N	%	±	15
Duty cycle at + 115 % U _N	%	1	00
Ambient temperature range ¹⁾	°C	-20 .	+60
Max. permitted coil temperature ²⁾	°C	1	80
Insulation class as per EN 60085			Н
Integrated free-wheeling diode		У	res
Coil length	mm		40
Connector type and IP protection class (with mating connector mounted)			pin, axial / up to IP6K6 ³⁾ , axial / up to IP6K9K ³⁾
Valve body and coil surface protection		Zinc-Nic	kel (ZnNi)


¹⁾ Deviation of data at request only

³⁾ Mating plug-in connectors are not included



²⁾ Standards ISO 13732-1 and ISO 4413 must be observed in regard to the surface temperatures occurring on the coils

Connection type, fastening and tie rods



 \triangle Only use fittings with deformable seal materials.

1	Valve type								
2	Specification type								
	-	Complete control block No. of working sections (1 0 (0 = 10 working sections))							
	х	Single modules (Inlet plate, Working section, end plate)							
3	Connec	tion type							
	В	BSPP acc. to ISO 1179-1							
	S	S AE acc. to ISO 11926-1 or SAE J1626							
4	valve se	eries							

Connection type			В	Countersink Ø in mm	5	\$	Countersink Ø in mm
Inlet plate	P1	Pump	G 1/2	38	7/8-14 UNF	SAE-10	38
	P2	Pump	G 3/8	32	3/4-16 UNF	SAE-8	32
	T3	Tank	G 1/2	30	7/8-14 UNF	SAE-10	30
	PM	Pump measuring port	G 1/4	25	7/16-20 UNF	SAE-4	25
Working section	A/B	Working ports	G 3/8	30	3/4-16 UNF	SAE-8	25
End plate	T1	Tank	G 1/2	37	7/8-14 UNF	SAE-10	37
	T2	Tank	G 1/2	30	7/8-14 UNF	SAE-10	30
	Z	Pilot drain	G 1/4	22	9/16-18 UNF	SAE-6	22
	С	Pilot oil supply	G 1/4	22	9/16-18 UNF	SAE-6	22

Fastening:

Use at least 3 of the 4 fixation points to mount the control block without tensioning.

Fastening screws:

- M8 or 5/16-24 UNF (SAE-2)
- Property class 10.9, fastening torque 25 Nm ± 3 Nm

Tie rods:

M8 tie rods with flange nut 13 mm, M_Z = 20 Nm ± 2 Nm

 \triangle Only use genuine RS160-EH tie rod kits.

Installation, usage and maintenance information


Installation, adjustment, maintenance must be done by authorized and trained staff.

The use of this product outside the specified technical limits, use of non-specified fluids and/or use of not genuine spare parts will cause the expiration of the warranty.

E 5.284.0/03.16

Interconnection examples

Parallel connection




Connecting two blocks parallel, as shown: Connect port T1 of the first block with port P1 of the second block, using adapter S16 and K16. Adapter S16 (HPCO = High Pressure Carry Over) disconnects the center channel from the tank channel. Adapter K16 disconnects the parallel channel from the center channel. The P2 ports of both blocks are connected to supply the parallel channel of the second block with pump pressure.

S16 is needed to prevent oil flow from the center channel of the first block to tank (T2 or T3) if a working section of the second block is operated.

K16 is needed to prevent oil flow to tank (T1, T2 or T3) of the second block if a working section of the first block is operated.


Serial connection



Connecting two blocks serial, as shown: Connect port T1 of the first block with port P1 of the second block, using adapter S16. Adapter S16 (HPCO = High Pressure Carry Over) disconnects the center channel from the tank channel. If operating a working section of the first block (full stroke) then operating a working section of the second block is not possible (priority circuit).

S16 is needed to prevent oil flow from the center channel of the first block to tank (T2 or T3) if a working section of the second block is operated.


Loadsensing pump connection



The RS160-EH valve block can also be operated with a Loadsensing pump. Therefore the adapter L16 is needed in port P1, which generates a throttled pressure signal for the pump controller. Port P1 is connected to the pump controller (LS port).

Example of a control block with inlet w/o unloading valve, end plate with external pilot oil supply


Connector types: AMP Junior Timer, 2-pin, axial




Example of a control block with inlet with unloading valve, end plate with internal pilot oil supply, manual emergency hand lever twice

Connector types: AMP Junior Timer, 2-pin, axial

1.0	Inlet plate U15 / Y2A / 210F
1.1	Unloading valve
1.2	Main relief valve
2.0.1	Working section BP4E
2.0.2	Working section SP4E
2.3	Electrohydraulic operation
2.3.1	Pressure control valve A side
2.3.2	Pressure control valve B side
2.4	Manual emergency hand lever
2.5.1	Working port valve A side
2.5.2	Working port valve B side
3.0	End plate E5E2 / 0H
3.3	Adapter for high pressure carry over
4.0	Type plate







a


9

Manual emergency hand lever: Neutral position and max. stroke (see section – Operation units)

assembled on A side








Control block fastening points (4x M8)

The fastening points are equal for all types of inlet and end plates.



No. of workin	g sections	1	2	3	4	5	6	7	8	9	10
L1	mm	82.5	114.5	146.5	178.5	210.5	242.5	274.5	306.5	338.5	370.5

ucture and sequence 1.	General (control block always defined from left to right)												
2		Inlet plate											
		1. Working section											
	2. Working section												
	n. Working section												
4.	End plate												
General													
Type:	RS16	4	-EH /	В	0								
Pos.	1.	2.		3.	4.								
1 55.				0.									
Pos. / designation:	Туре с	ode:				Description	/ function:		Comment:				
Open-center valve series	RS16				$\overline{}$		valve, Size 2						
No. of working sections							(0 = 10 working s	sections)	max. 10 working section				
Spec. / identification of single module	X				_		rking section or e						
Connection thread	В				\rightarrow	BSPP acc. to		P - 2-					
	s				-		SO 11926-1 or S	AE J1626					
4. Valve series	0				-		nstallation and co						
						dimensions							
Inlet plate													
Type:	P15	1	200F	1	L								
	U15	1	Y1D	1	Р								
Pos.	1.		2.		3.								
Pos. / designation:	Туре с	ode:				Description	/ function:		Comment:				
1. Basic type													
	P15					P with P2 por	rt 1 version	5 port size P/T	Port size 5: BSPP: G1/2 SAE: 7/8-14 UNF				
2. Main relief valve													
	_												
	F						ting in bar, 3-digi · <i>(TBS</i>)	t, fixed set,	see section – Working port valves				
	F					max. 250 bar	(TBS)	t, fixed set,	Working port valves				
3. Cavity for fitting	P						(TBS)	t, fixed set,					
3. Cavity for fitting	P					max. 250 bar Plug screw (<i>I</i>	(TBS)		Working port valves				
3. Cavity for fitting	P 0					max. 250 bar Plug screw (I Parallel chan	P110)	center channel	Working port valves				
3. Cavity for fitting	P					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16	nel connected to	center channel	Working port valves				
3. Cavity for fitting	P 0					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16	nel connected to	center channel	Working port valves				
3. Cavity for fitting	0 1					max. 250 bar Plug screw (I Parallel chan channel (K16 Throttled cor	nel connected to	center channel	Working port valves				
Pos. / designation:	0 1					max. 250 bar Plug screw (I Parallel chan channel (K16 Throttled cor	refresh	center channel	Working port valves				
	P 0 1 L Type c					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description	nel connected to nel disconnected to nel disconnected to nection (Loadse L16)	center channel I from center Insing pumps)	Working port valves w/o pressure relief valve Comment:				
Pos. / designation:	0 1 L					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description	nel connected to nel disconnected (i) neection (Loadse L16) / function:	center channel I from center Insing pumps)	Working port valves w/o pressure relief valve Comment:				
Pos. / designation:	P 0 1 L Type c					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P	r (TBS) P110) Inel connected to nel disconnected: Innection (Loadse L16) I function: ding valve 1 verify	center channel If from center Insing pumps)	Working port valves w/o pressure relief valve Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type	P 0 1 L L Type c					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P	nel connected to nel disconnected (i) neection (Loadse L16) / function:	center channel If from center Insing pumps)	Working port valves w/o pressure relief valve Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve	P 0 1 1 L					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P	r (TBS) P110) Inel connected to nel disconnected: Innection (Loadse L16) I function: ding valve 1 verify	center channel If from center Insing pumps)	Working port valves w/o pressure relief valve Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type	P 0 1 L L Type c					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P	r (TBS) P110) Inel connected to nel disconnected: Innection (Loadse L16) I function: ding valve 1 verify	center channel If from center Insing pumps)	Working port valves w/o pressure relief valv Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type	P 0 1 1 L					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P Unloading va 12 V 24 V	r (TBS) P110) Inel connected to nel disconnected: Innection (Loadse L16) I function: ding valve 1 verify	center channel If from center Insing pumps)	Working port valves w/o pressure relief valv Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type Supply voltage DC	P 0 1 L L Type c					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (i Description U with unload 5 port size P Unloading va 12 V 24 V AMP - Junior	r (TBS) P110) Inel connected to nel disconnected (i) Innection (Loadse L16) I function: ding valve 1 verify	center channel If from center Insing pumps)	Working port valves w/o pressure relief valve Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type Supply voltage DC	P 0 1 L U15 Y1					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (i Description U with unload 5 port size P Unloading va 12 V 24 V AMP - Junior	r (TBS) p110) nel connected to nel disconnected; nnection (Loadse L16) / function: ding valve 1 verify live normally ope	center channel If from center Insing pumps)	Working port valves w/o pressure relief valve Comment: Port size 5: BSPP: G1/2				
Pos. / designation: 1. Basic type 2. Unloading valve Valve type Supply voltage DC Connector type	P 0 1 L U15 Y1					max. 250 bar Plug screw (I Parallel chan Parallel chan channel (K16 Throttled cor on request (I Description U with unload 5 port size P Unloading va 12 V 24 V AMP - Junior Deutsch - DT	r (TBS) P110) Inel connected to nel disconnected to nel disconnected to nection (Loadse L16) I function: ding valve 1 very/T live normally ope Timer, 2-pin, ax 104, 2-pin, axial	center channel If from center Insing pumps) Ision In	Working port valves w/o pressure relief valv Comment: Port size 5: BSPP: G1/2				

■ Type code

3.	Working sections									
	Type:	BP4E	1	12AA	1			EHB2D-1		
		SP4E	1	14AZ	1	P-180F	1	EH01A		
	Pos.	1.		2.		3.		4.		


Pos. / designation:	Type code:	Description / function:	Comment:
1. Basic type			
	B_4_	w/o working port valves 4 port size A/B	Port size 4: BSPP: G3/
	S_4_	With working port valves	SAE: 3/4-16 UNF
	_P	Parallel section	
	E	Electrohydraulic operation	
2. Spool			
1 Type	1	4/3-way, double acting	
	2	3/3-way, single acting	
	4	Motor spool	
2 Max. volume flow	_1	10 l/min	
	_2	20 l/min	
	_4	45 l/min	
	_6	60 l/min	
3 Details	A_	Standard	
4 Release specification	A	Port A and B closed in neutral position; no further release	
	z	Port A and B throttled to tank in neutral position	
	X	Port A throttled to tank in neutral position	
	Y	Port B throttled to tank in neutral position	
	T	Port A and B throttled to tank	
	U	Port A throttled to tank	
	W	Port B throttled to tank	
3. Working port valve		<u> </u>	'
	F	Pressure setting in bar, 3-digit, fixed set, max. 250 bar (TBS)	see section – Working port valves
	Α	Anti-cavitation valve (SB110)	
	Р	Plug screw (P110)	w/o pressure relief val
4. Operation units			
1 Basic type	EH0	electrohydraulic w/o emergency hand lever axis	
	EHA	electrohydraulic with emergency hand lever axis on A side	
	EHB	electrohydraulic with emergency hand lever axis on B side	
2 Supply voltage DC, connector t	ype1	12 V	
	2	24 ∨	
	A	AMP - Junior Timer, 2-pin, axial	
	D	Deutsch - DT04, 2-pin, axial	
3 Mechanical emergency hand le		Short hand lever for manual emergency operation	

4.	End plate					
	Type:	E5E	2	1	Z	Н
		E5E	1	1	0	С
	Pos.	1.	2.		3.	4.

Pos. / designation:	Type code:	Description / function:	Comment:
1. Basic type			
	E5E _	End plate 5 port size P/T E electrohydra	ulic Port size 5: BSPP: G1/2; SAE: 7/8-14 UNF
2. Pilot pressure supply			
	1	External pilot pressure oil supply	
	2	Internal pilot pressure oil supply	
3. Pilot drain			<u> </u>
	0_	Pilot drain external	
	Z_	Pilot drain connected internal to T	
4. Center channel precharging	g valve / HPCO		
	_c	With center channel precharging valve	
	_ H	With high pressure carry over (HPCO)	
	0	w/o option	




Example of a control block with unloading valve in the inlet plate and internal pilot oil supply in the end plate



General	RS 163-EH / B0
Inlet plate	U15 / Y2D / 230F
1. Working section	SP4E / 12AA / 250F – 250F / EHB2D-1
2. Working section	SP4E / 14AA / A – A / EHB2D-1
3. Working section	SP4E / 22AA / 250F – P / EHB2D-1
End plate	E5E2 / 0C

Example of a control block with external pilot oil supply and HPCO in the end plate



General	RS 165-EH / B0
Inlet plate	P15 / 230F / 0
1. Working section	BP4E / 12AA / EHB1A-1
2. Working section	SP4E / 11AA / 250F – P / EHB1A-1
3. Working section	BP4E / 12AA / EHB1A-1
4. Working section	SP4E / 44AA / A – A / EHB1A-1
5. Working section	SP4E / 11AA / 250F – P / EHB1A-1
End plate	E5E1 / ZH

Notes	
	ဖွ
	E 5.284.0/03.16
	284.0
	E 5.

Note

The information in this brochure relates to the operating conditions and applications described.

For applications and operating conditions not described, please contact the relevant technical department.

Subject to technical and other changes.



Head office HYDAC INTERNATIONAL GMBH Nordhydraulic HYDAC INTERNATIONAL

Industriegebiet 66280 Sulzbach/Saar Germany

Tel.: +49 6897 509-01 Fax: +49 6897 509-577

E-mail: mobilevalves@hydac.com Internet: www.hydac.com